


**CP4 to LA400 Older Model, RSW12U/V Older Model,
LA412s, RSL12VH, GA400/420D**



RED to + Positive AC
PWR/SOLAR or to battery

BLACK to - Negative AC
PWR/SOLAR or to battery

WHITE to CTRL PWR

BLUE to OPEN

YELLOW is not used